



Frequently Asked Questions

Proper Filling of Single-Strand Tendon Stressing Pockets

Answer from the PTI DC-70 Special Topics Committee

Revised July 2010 • Issue No. 11

Primary Author:
Bob Sward

Q What is the proper material and procedure for filling single-strand tendon stressing pockets?

A As the first line of defense for the corrosion protection of the stressing anchorage, a quality stressing pocket patch is essential for the long-term durability of the post-tensioning system. A premixed cementitious non-shrink grout described in the following and applied correctly to a well-prepared surface is required for filling single-strand tendon stressing pockets.

A product best suited as a patch material is a high-quality premixed cementitious chloride-free non-shrink grout, mixed with limited amount of water per manufacturers' recommendation for use as repair material. These repair grouts are designed specifically for filling concrete voids in vertical and overhead applications and are suitable for filling single-strand stressing pockets. All major cementitious material suppliers have prepackaged non-shrink grouts.

The key to a quality stressing pocket patch is the use of the right patch material, the recommended surface preparation, and the proper mixing and application. These repair grouts must be mixed, applied, and cured per the manufacturer's recommendations. Stressing pockets should be free from all PT coating, grease, form release agents, dirt, loose concrete, debris, or any deleterious material. Although it is accepted practice to place a small amount of PT coating or grease on the tip of the pocket former that is inserted into the anchor wedge cavity (particularly with standard nonencapsulated anchorages), any portion of the pocket former that comes into contact with the surrounding concrete should be free from all PT coating, grease, and form release.

The inside surface of the pocket former recess should be cleaned with a wire brush or similar to ensure the proper bond of the patch material; a bonding agent may be applied. The recess must be immediately protected with filling material. An inspection of the surface preparation and filling of the anchorage pockets is highly desirable.

BACKGROUND

Many post-tensioning recommendations, including PTI Recommendations,¹ have long specified non-shrink, nonmetallic grouts with no chlorides for filling stressing pockets. In reality, these are shrinkage compensating grouts that expand in either the plastic and/or the hardened states to counteract the effects of shrinkage. These are high-quality grout materials that work well in confined spaces such as beneath base plates; in the application of a stressing pocket patch, the benefit is derived from its consistent quality that ensures a tight grout plug sealing the stressing pocket. Most non-shrink grout's Product Data Sheet will state material application limitations.

Plastic pocket formers currently available for most post-tensioning systems are specifically designed for ease of stripping and do not require any form release agents. If PT coating, grease, or any form of release agents have been applied to the sides of the pocket former, it will be necessary to physically remove the contaminants from the concrete surface inside of the stressing pocket prior to filling the pocket. This can be done by either sand blasting or using a wire brush.

DEFINITIONS

Grout, PT stressing pocket—a premixed cementitious chloride-free non-shrink grout mixed with limited amount of water per manufacturers' recommendation for use as repair material (non flowable). These repair grouts are designed specifically for filling concrete voids in vertical and overhead applications and are suitable for filling single-strand stressing pockets of post-tensioning tendons.

REFERENCES

1. *Specification for Unbonded Single Strand Tendons*, second edition, Post-Tensioning Institute, Farmington Hills, MI, 2000, 36 pp.

This document is intended for the use of professionals competent to evaluate the significance and limitations of its contents and who will accept responsibility for the application of the materials it contains. The Post-Tensioning Institute reports the on-going material as a matter of information and therefore disclaims any and all responsibility for application of the stated principles or for the accuracy of the sources other than material developed by the Institute. The Post-Tensioning Institute, in publishing the Frequently Asked Questions, makes no warranty regarding the recommendations contained herein, including warranties of quality, workmanship, or safety, express or implied, further including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. **THE POST-TENSIONING INSTITUTE SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES BEYOND REFUND OF THE PURCHASE PRICE OF THIS ISSUE OF FREQUENTLY ASKED QUESTIONS.**

The incorporation by reference or quotation of material in the Frequently Asked Questions in any specifications, contract, documents, purchase orders, drawings, or per diems shall be done at the risk of those making such references or quotation and shall not subject the Post-Tensioning Institute to any liability, direct or indirect, and those making such reference or quotation shall waive any claims against the Post-Tensioning Institute.

Copyright © 2010 by Post-Tensioning Institute
All Rights Reserved
Printed in U.S.A.